



## Manual Regeneration Instructions

Manually cycle your Kinetico Water Softener by performing the following:

- Insert a #2 Phillips head screwdriver in the center cap.
- While pushing down firmly, turn the screwdriver slowly clockwise until you hear a slight rush of water.
- Remove screwdriver; system is now entering its cleaning cycle.
- Repeat the process in 2 hours to regenerate the second tank.

